

## VI.5.3D-FREQPLOT PROGRAM FCST HCL TECHNIQUE FREQPLOT

### Purpose

Technique FREQPLOT sets whether frequency plots will be produced by Function ESP.

Valid values are NO (0) and YES (1).

The Global default value is YES (1).

This Technique is Nonuniversal.

### Form of Input

FREQPLOT(integer)

where integer is 0 or 1 specifying whether or not frequency plots will be produced

### Example

FREQPLOT(0)

Frequency plots will not be produced.